

Autolatch Restrictor Fitting Instructions



It is important that these instructions are followed to ensure the correct installation and function of the Maco Autolatch casement window restrictor.

- ✂ Position the Autolatch onto the sash so that the window opening is restricted to no more than 100 mm. It is normal practice to fix the restrictor and frame stud in the same position as the friction stay hinges.



Important: Please note that open face of the Autolatch arm must face the inside of the window.

- ✂ Position and fix the frame stud so that when the window is closing the front edge of the restrictor is central with the frame stud.



Important: Please ensure that you use the correct height frame stud.

- ✂ It is our recommendation that only stainless steel screws are used.

