




MAINTENANCE INSTRUCTIONS

Your new door has been fitted with a high quality locking system from Maco UK, by following some simple maintenance instructions it will give you many years trouble free service.


1. The door locks main lock casing which is hidden within the door is supplied with a high performance lubricant and DOES NOT require any further lubrication.



2. The centre latch and deadbolt must be lubricated once yearly with a technical vaseline or lubrication grease.



3. Locking Bolts, Hook locks and locking cams and other visible moving parts must be lubricated once yearly.



4. DO NOT use any rust removers, silicone sprays, WD40 or similar!

